



V3-10.15

ASSEMBLY INSTRUCTIONS



1.84m x 0.70m x 1.30m

Product Name: Large Log Store Pressure Treated

PLEASE KEEP THESE INSTRUCTIONS

Pressure Treated products should not be treated with any other products for the first month.

Zest4Leisure
01352752555 - sales@zest4leisure.co.uk

Large Log Store Assembly Instructions

Requires 2 person assembly.

Tools required:- Corded/ Cordless Drill, Tape Measure, Pozidrive Bit/Screwdriver, Spirit Level. 3mm Drill Bit required in order for you to drill all screw holes before construction.

Log Store Fixings List		
Item	Description	Quantity
A	4x40mm Screws	6
B	4x60mm Screws	8
C	Floor	1
D	Left & Right Sides	2
E	Back Corner Supports	2
F	Lathed Roof	1



1) Position part C on a flat surface



2) Position part D with the lowest angle to the back ensuring board overlaps base. Using 3mm drill bit, pre drill 3 holes across overlap board. Using 3no item A screws fix side to base, repeat on opposite side.



3) Place Roof (Item F) across both sides evenly and using a spirit level ensure end panels are straight. With a tape measure, measure from outside of roof measure 70mm in, this is the external overlap. Using 3mm drill bit drill all four corners as shown in the photograph using 4x60 screws (Item B) Place in pre drilled holes.



4) Place Back corner supports (Item E) as shown in photograph. Pre drill holes with 3mm drill bit. Using two 4x60mm screws (Item B) screw brackets into place. Repeat on opposite side.

The assembly is now complete.